Programming

Individual Abbreviated Number

★51 ★ (0-9) ★ No. #

Erase One Number

#51×(0-9)#

Erase All Numbers

#51#

Dialog 3211, 3212, 3213



Number



Adapting the Telephone

Tilting Display on Dialog 3212 and 3213

Tilting Foot Consoles





Symbol Explanations


Lift the handset

(0-9)

Press a wanted digit on the keypad

Diversion David

Pre-programmed key Programmable key



Key below the display (Dialog 3213 only)



Replace the handset

Press the key



Press repeatedly the key as many times as shown



Extinguished lamp



Steady light



- Flashing lamp


QUICK REFERENCE GUIDE - System telephones Dialog 3210, 3211, 3212, 3213

Volume Control

At Idle or when Ringing: **Tone Ringer Volume**



During Calls:





Tone Ringer Character

Dialog 3211, 3212, 3213 Program (0-9) Program







Ringing Options

Dialog 3211, 3212, 3213












- 1 Normal ringing 2 Delayed normal
- ringing 3 Two rings than flash
- connection, (function key controlled
 - 6 Immediate speech







Lamp Indications

Mute when Ringing

Rapidly flashing lamp Incoming call

Slowly flashing lamp

The line is put on hold

Light with short breaks

Ongoing call

Steady light

The function is active or a supervised line is busy

Dialog 3210, 3211, 3212, 3213

System Telephones for MD110

Quick Reference Guide



Ericsson Enterprise AB All rights reserved. For questions regarding the product, please contact your Ericsson Enterprise Certified Sales Partner. www.ericsson.se/enterprise

© Ericsson Enterprise AB 2001 EN/LZT 102 2584 RC



Answer Calls

Access 1

All Other Lines

Handsfree

(Dialog 3211, 3212, 3213 only)

On Another Extension (Call pick-up)



Dial abbreviated number

Dial number

★★ (0-9)

David

Make Calls

Ordinary Calls

Common Abbreviated Number

Individual Abbreviated

Number **Speed Dial**

(Dial by a Function Key)

Last External Number Redial

Dial by Number Log* (Dialog 3213 only)





Accept a Second Call

Activate/Cancel



During Connected Calls

Switch to Loudspeaker (Dialog 3211, 3212, 3213 only)

Switch to Handsfree (Dialog 3211, 3212, 3213 only)

Switch to Handset

Mute/Cancel





Individual **Resume Call**

Common Resume Call - Own Ext.

Resume Call - Another Extension

Access

9 Dial digits

Access

Access

Call the extension where

8

Inquiry

Inquiry **Activate** Call next party Access **Alternate Between Calls** (Refer Back) Access **Return to First Party**

Transfer

Transfer to Another Extension





Transfer (Press before or

Conference

Activate



Call next party 3 (Press after answer)

When Busy Signal or No Answer

Activate Callback

Cancel One Callback *6 * Ext.. #

Cancel All Callbacks

#6#

Send Call Waiting

5 (At busy signal) Wait on the line

***2#**

Call Forwarding

Diversion Diversion Diversion

#2# Cancel or

Diversion No Answer * 21 # Cancel #21# **Diversion Busy * 22 #**

Cancel #22#

Diversion Override *1 * Ext. #

Follow-Me

Activate (from your **★2** ★ New ext. # own extension)

Cancel #2#

Re-direct from **★2** ★ Own ext. ★ New ext. # **Answer-Point**

Cancel from #2 * Own ext. # **Answer-Point**

External Call Forwarding + 23 # External code/No. #

Cancel #23#

Personal Number*

Activate or Change Profile

*10 * (1-5) #

Cancel #10#

General Cancellation

Cancel All Activated Features

#0#

Voice Mail*

Entering Your Mailbox:

In General

Dial Voice Mail number Follow recorded instructions

New Message Received



Follow recorded instructions

Absence Information (Diversion Message)*

Activate

Cancel

★24 ★ Reason ★ HHMM/ #

Reason Codes:

0 Lunch MMHH 1 Out: Day MMDD

2 Out: Bus. HHMM (On business)

3 Meeting HHMM

7 Out: III 8 Seminar

5 Absent

6 Vacation

4 Out: Trip MMDD

9 Jury Duty MMDD

MMDD

MMDD

MMDD

MMDD

#24#

Authorization Code³

Common Code

Common # External code & No. One Single Call

Individual Code

Unlock Your Telephone #76 ★ Individual #

★76★ Individual # **Lock Your Telephone**