AASTRA / MITEL ADDITIONAL INSTRUCTIONS – revised 2/8/2018

Number Log

Use arrows key to highlight CallList Options **Call List** (all calls – unanswered, incoming, outgoing) **Unanswered calls Outgoing calls Incoming calls** Use the Up or Down soft key to make a selection Press Select Options Call The number corresponding to the displayed logged call information entry is dialed. (This feature can only be used to call back **ON-CAMPUS EXTENSIONS** or outgoing numbers previously dialed) Up Bring the user up one element in the list **Down** Bring the user down one element in the list More Shows the following soft-keys Exit Exit the function **Delete** Delete the highlighted entry, and the list shows the next element in its position. Return Go back to the previous soft-keys

Ring Options

Use arrow key to highlight **Program** Press **Select** You will see in the display: Program mode key **Ring type:** Press the **line button** to be programmed Press **number of ring option** Press the **line button** again Press **Exit**

- 0 = Silent (flashing light only)
- 1 = Normal ringing
- 2 = Delay then normal ringing
- 3 = 2 quiet rings then just flashing light
- 4 = Delay then 2 quiet rings then just light
- 5 = (not in use)
- 6 = Automatically connects to speakerphone

To check the ring option for a **line button** Use arrow key to highlight **Program** Press **Select** You will see in the display: Program mode key **Ring type:** Press the **line button** you are checking and you will see the ring option in the display.

Ring Character

Use arrow key to highlight **Program** Press **Select** You will see in the display: Program mode key **Ring type:** Press **0-9** to hear sample ring tone Once you hear the tone you prefer, press **Exit**

Programmable Function Buttons

Use arrow key to highlight **Program** Press **Select** You will see in the display: Program mode key **Ring type:** Press the function button to be programmed You will see in the display: NameKey, 1-20 digits Press the sequence of keys to be stored Press the same function button again Press **Exit**